This part list contains the service parts for the air cooled, water cooled and remote air cooled C1448, C1848, C2148 ice machines.

To avoid costly and time consuming errors, double check the model and voltage before ordering a part.

Note: These abbreviations are used in this list:


- AC = Air Cooled
- ■WC = Water Cooled
- •RC = Remote Cooled
- ●HGV = Hot Gas Valve
- ◆TXV = Thermostatic Expansion Valve
- ●Volt = Voltage
- Sol Vlv = Solenoid Valve
- Hdwe = Hardware

#### **Table of Contents**

Cabinet	· Page 2
Interior Parts · · · · · · · · · · · · · · · · · · ·	· Page 3
Evaporator Compartment · · · · · · · · · · · · · · · · · · ·	· Page 4
Air Cooled Refrigeration System · · · · · · · · · · · · · · · · · · ·	· Page 5
Air Cooled Mechanical & Electrical · · · · · · · · · · · · · · · · · · ·	· Page 6
Water Cooled Refrigeration System	· Page 7
Remote Refrigeration System	· Page 8
Electrical & Control Box	· Page 9
Compressors	· Page 10
Compressor Mounting Hardware · · · · · · · · · · · · · · · · · · ·	· Page 10
Crankcase Heaters · · · · · · · · · · · · · · · · · · ·	· Page 10
Remote Condenser, ERC311 and ERC611 · · · · · · · · · · · · · · · · · ·	· Page 11


Scotsman 800-533-6006 www.scotsman-ice.com

### Cabinet




Item	Part		7	02-4214-03	Trim strip
Number	Number	Description	8	A38553-023	Right side panel assy
1	A38941-023	Top panel, w/trim strips	8a	02-4215-01	Receptacle
1a	02-4221-01	Left trim strip	8b	03-3804-01	Screw receptacle
1b	02-4221-02	Right trim strip	9	02-4067-03	Side panel support
2	02-4184-01	Evaporator cover		for water cool 02-4067-04	ed and remote models Side panel support
2a	03-0727-05	Screw		for air cooled	
3	A39045-001	Front panel stiffener	10	A39222-001	Filter guide
4	A38552-025	AC Front panel assembly,	11	02-4212-01	Air filter
	includes filters labels.	s, trim strip, gussets and	12	02-4224-01	Louver panel
	A38552-024	WC, or RC front panel	12a	A39238-001	Louver bracket
	assembly, incl labels	udes trim strip, gussets and	13	A38551-023	Left side panel, AC
4a	02-4216-01	Top gusset		A38551-024	Left side panel WC, RC
4b	02-4217-01	Bottom gusset	14	03-1404-12	Screw
5	03-1735-03	Screw, front panel	15	A30911-015	Machine straps
6	02-4284-01	Bezel, full window	16	16-0355-00	Inlet water fitting, flare
6a	02-4284-02	Bezel, partial window	17	03-1419-17	Flat head screw

#### **Interior Parts**



		0,4			
Item	Part		15	A39030-021	Water level sensor
Number	Number	Description	16	12-2920-22	Water pump
1	15-0411-00	Strike	17	12-2934-22	Harvest assist solenoid
2	no number	Base, insulated	18	02-4178-01	Reservoir cover
3	03-3804-01	Receptacle	19	02-4332-01	Sensor cover
4	A38732-001	Side panel mount	20	02-4182-01	Pump hose
5	A38629-001	Strut	21	13-0674-02	Fill hose order by ft (18")
6	A38582-001	Brace		15-0821-01	Fill hose, -6 CE models
7	A39281-001	Control box top	22	02-4175-01	Rt side res cover
8	A38537-001	Control box side	23	A39030-022	Level sensor
9	no number	Back panel	24	11-0572-21	Temp probe assy
10	12-2922-02 12-2912-01	Inlet water sol vlv, 230 volt Water valve rebuild kit			
10a	11-0568-02	Inlet water sol vlv, CE mod			
11	11-0564-02	Purge valve, 230 volt			
12	A38862-002	Drain tube			
13	A38862-001	Drain hose			
14	02-4177-01	Water pump bracket			

#### **Evaporator Compartment**




Item	Part		6	A3903
Number	Number	Description	7	02-410
1	02-4065-01	Water distributor cover	8	11-056
2	02-4064-01	Water distributor, left	9	11-056
2a	02-4064-02	Water distributor, right	10	13-094
3	02-4205-01	Mounting bracket, left	11	03-386
3a	02-4205-02	Mounting bracket, right	Note: Item	7 includ
4	see table	Evaporator		

	small cube	medium cube
Right	A38628-023	A38628-024
Left	A38628-021	A38628-022

6	A39031-021	Ice thickness sensor
7	02-4100-23	Curtain
8	11-0563-03	Curtain switch
9	11-0563-02	Curtain switch magnet
10	13-0943-01	Gasket tape
11	03-3868-01	Screw


Note: Item 7 includes item 9, shipped loose.

### **Air Cooled Refrigeration System**




Item	Part	
Number	Number	Description
1	18-8892-01	Condenser, AC
2	16-1130-02	TXV
	02-4045-01	Insulation Danfoss TXV
3	11-0566-22	Fan cycle pressure sw.
4	02-3319-01	Dryer
5	11-0493-01	Hot gas valve, 230 volt
	12-2719-22	230 volt coil
	12-2733-30	HGV rebuild kit
6	16-1063-01	Strainer
7	16-0832-20	Access valve
	16-0832-03	Port cap
	16-0832-02	Stem cap
8	see page 10	Compressors
9	see page 10	Compressor mounting hdw

#### **Air Cooled Mechanical & Electrical**




Item	Part	
Number	Number	Description
1	18-8927-01	Fan motor
2	18-8882-01	Fan blade
3	02-3692-21	Drain adapter - also for WC and RC
4	A38682-001	Fan shroud
5	A38554-001	Fan motor bracket
6	02-4067-04	Side panel support - AC
7	03-1645-01	Screw

#### **Water Cooled Refrigeration System**




Item	Part		11	11-0478-01	Water regulating valve,
Number	Number	Description		11 0170 01	C1448W, C1848W
1	18-8865-21 C1848	Condenser, WC C1448.		11-0478-02	Water regulating valve C2148W
	18-8931-21	Condenser, WC C2148	12	02-4067-03	Side support
2	16-1130-02	TXV		0_ 1001 00	
	02-4045-01	insulation Danfoss TXV			
3	11-0501-21	High pressure sw.			
4	02-3319-01	Dryer			
5	11-0493-01	Hot gas valve, 230 volt			
	12-2719-22	230 volt coil			
	12-2733-30	HGV rebuild kit			
6	16-1063-01	Strainer			
7	16-0832-20	Access valve			
	16-0832-03	Port cap			
	16-0832-02	Stem cap			
8	see page 10	Compressors			
9	see page 10	Compressor mounting hdw			
10	02-2628-02	Receiver			
		Novembe	er 2006		

Page 7



Item	Part		11	11-0493-01	Liquid line valve or HGV,
Number	Number	Description			230 volt
1	16-1026-01	Receiver	12	16-0832-20 16-0832-03	Access valve Port cap
2	16-1130-02	TXV		16-0832-02	Stem cap
	02-4045-01	insulation Danfoss TXV	13	16-1063-01	Strainer
3	16-0850-01	Discharge quick connect	14	A37211-001	Top receiver bracket
4	16-0850-03	Liquid quick connect	15	A37212-001	Bottom receiver bracket
5	02-3319-02	Drier	16	02-3692-21	Drain adapter
6	16-1030-01	Liquid line access valve	17	16-1122-21	Accumulator, kit
7	see page 10	Compressors	w/insula	ation	
8	see page 10	Compressor mounting hdw			
8a	see page 10	Crankcase heater			
9	02-4067-03	Side panel support,			
10	11-0501-22	High pressure cut out			

#### **Electrical & Control Box**



Item	Part		10	12-2686-01	Fuse, 50 Hz only
Number	Number	Description	11	12-2687-01	Fuse holder
1	12-2469-02	Contactor, 230, single ph	12	18-8840-02	Bracket
	12-2533-01	Contactor, three phase	Wiring Ha	arnesses (not ill	ustrated)
2	12-2924-02	Transformer, 230 volt	13	12-2931-01	Power harness, A & W
2a	12-2369-01	Transformer, 50 Hz		12-2931-02	Power harness, Remote
3	12-1213-11	Snap bushing	Power	harness connec	cts to J1 on controller
4	12-1213-15	Snap bushing	14	12-2937-01	Hi voltage harness, A & W
5	11-0550-20	Service controller, fits all		12-2938-01	Hi voltage harness, Rem
		Prodigy cubers		12-2944-01	Hi voltage, 50 Hz A & W
6	02-4076-01	Control box door		12-2944-02	Hi voltage, 50 Hz, Rem
	02-4189-01	Overlay label	Hi volta	age harness has	s the 8 pin connector
7	A39216-001	Barrier	15	12-2928-02	Water level sensor harness
8	see next page	e Run capacitor			
9	see next page	PTCR -			

#### **Compressors**

Model	Electrical	Compressor	Run Capacitor	PTCR
C1448-32	208-230/60/1	18-8749-22	18-1902-55	18-8840-01
C1448-6	230/50	18-8749-27	18-1902-55	18-8840-01
C1448-3	208-230/60/3	18-8749-24	_	-
C1848-32	208-230/60/1	18-8751-23	18-1902-58	18-8840-01
C1848-6	230/50	18-8751-27	18-1902-58	18-8840-01
C1848-3	208-230/60/3	18-8751-25	-	-
C2148-32 - WC	208-230/60/1	18-8930-24	18-1902-27	18-8840-01
C2148-6 - WC	230/50	18-8930-26	18-1902-59	18-8840-01
C2148-3 - WC	208-230/60/3	18-8930-25	-	-
C2148-32 - RC	208-230/60/1	18-8923-22	18-1902-27	18-8840-01
C2148-6 - RC	230/50	18-8923-26	18-1902-59	18-8840-01
C2148-3 - RC	208-230/60/3	18-8923-23	_	-

#### **Compressor Mounting Hardware**


Model	Bolt	Washer	Grommet	Sleeve
C1448, C1848	03-1420-20	03-1407-07	18-2300-27	18-2300-26
C2148	03-1405-20	03-1407-07	18-2300-27	18-2300-26

#### **Crankcase Heaters**

Model	Crankcase heater*
C1448R, C1848R, C2148R	18-2308-01

<sup>\*</sup> Included with replacement compressor

#### Remote Condenser, ERC311 and ERC611



Item	Part			
Number	Number	Description		
1	03-1405-08	Screw		
2	02-3575-01	Fan guard		
3	16-1044-01	Headmaster		
4	18-8816-01	Fan blade - ERC311		
	18-8820-01	Fan blade - ERC611		
5	12-2651-01	Fan motor - ERC311		
	12-2717-01	Fan motor - ERC611		
Not Shown:				
	A37169-001	Leg		
	A37170-001	Leg brace - ECR311		
	A37296-001	Leg brace - ERC611		
	03-1645-01	Screw for legs		
	16-0850-01	Quick connect, discharge		
	16-0850-03	Quick connect, liquid		